

SNIPER



INF-WGP-01
LEADER
Wireless Gamepad

USER'S GUIDE

包裝內容

指揮者無線控制器 x 1

USB數據充電線 x1

使用說明書 x1


系統需求

Android 3.2或是更高版本

Win10/8.1/8/7/Vista/XP

iCade

按鍵配置



❶ L1/L2按鍵

❷ R1/R2按鍵

❸ 十字按鍵

❹ 開機鍵

❺ 左邊3D類比搖桿

❻ 右邊3D類比搖桿

❼ 藍牙指示燈

❽ 充電/電源指示燈

❾ SELECT鍵

❿ START鍵

Ⓨ Y. Y鍵

Ⓧ X. X鍵


Ⓐ A. A鍵

Ⓑ B. B鍵

夾具使用方法



①



②




③




④

初次連接



安卓版本藍牙配對操作方法:

1. 短按HOME鍵 1 秒，開機
(開機指示燈進入慢閃狀態)
2. 待藍牙指示燈熄滅後，按住”X”鍵不放，再按下HOME鍵1 秒，等藍牙LED指示燈快閃進入可配對狀態後放開按鍵
(長按HOME鍵 3 秒，所有指示燈熄滅，手把會關機)
3. 藍牙LED指示燈快閃代表進入可配對狀態
4. 打開手機藍牙搜索選擇手把並點選配對
(需在手把處於可配對模式)
5. 配對成功後,LED指示燈常亮



二次連接 / 回連:

1. 待藍牙指示燈熄滅後，按住”X”鍵不放，再按下HOME鍵1 秒，等藍牙LED指示燈快閃進入可配對狀態後放開按鍵
2. 打開手機藍牙搜索選擇手把並點選配對
(需在手把處於可配對模式)
3. 配對成功後,LED指示燈常亮


註1:

手機藍牙不同版本連接時會有不同的操作要求,如果手機端顯示需要輸入密碼,預設密碼為0000 或 1234 (需在藍牙指示燈持續閃爍期間完成輸入並連接)

註2:

若需要將” INF-WGP-01 ” 配對至另一隻手機,請將原先手機的配對解除,或是將原手機的藍牙關閉,即可透過另外一隻手機連線配對

i Cade連接方式



1. 按住”B”鍵不放,再按下HOME鍵1秒,等藍牙LED指示燈快閃進入可配對狀態後放開按鍵
2. 藍牙LED指示燈快閃代表進入可配對狀態
3. 打開手機藍牙搜索選擇手把並點選配對(需在手把處於可配對模式)
4. 配對成功後,LED指示燈常亮

有線連接

1. 安卓模式:需要在手柄與設備之間利用OTG與傳輸線進行連接。
當手柄上的紅色充電燈亮起時,表示連接成功,可正常在安卓設備上使用
2. PC平台:將數據線的USB端插入PC的USB接口,另一端插入手柄,手柄上的紅色充電燈亮起時,表示連接成功,可正常在PC設備上使用

指示燈狀態說明

類型	顏色	狀態描述
藍牙指示燈	藍色	未連接:慢閃 等待配對:快閃 配對成功:常亮
充電指示燈	紅色	充電時:常亮 充滿:紅燈熄滅 低電量:紅燈閃爍

注意事項

- 1.當手把無法正常操作的時候,可使用背面的左下角的小孔回覆手把預設狀態
- 2.請不要將產品儲存在潮濕或是高溫的地方
- 3.請勿自行拆解產品,以免造成不必要的損傷
- 4.產品內置電池,請勿隨意丟棄
- 5.第一次使用時請先充飽電
- 6.建議連續充電時間不要超過兩個小時
- 7.請勿自行拆解、重摔與接近水/火源


本產品符合低功率電波輻射性電機管理辦法 第十二條~第十四條等條文規定
*經型式認證合格之低功率射頻電機,非經許可,公司、商號或使用者均不得擅自變更頻率、加大功率或變更原設計之特性及功能。
*低功率射頻電機之使用不得影響飛航安全及干擾合法通信;經發現有干擾現象時,應立即停用,並改善至無干擾時方得繼續使用。
*前項合法通信,指依電信法規定作業之無線電通信。
*低功率射頻電機須忍受合法通信或工業、科學及醫療用電波輻射性電機設備之干擾。



遊戲相容網址



www.infans.com.tw




Package contents

Leader Wireless Gamepad
USB cable
User's Guide

System requirements

Android 3.2 or up
Windows system PC
iCade

Buttons & function



- 1 L1 /L2 Button
- 2 R1/R2 Button
- 3 Direction Button
- 4 Home Button
- 5 Left Analog Stick

- 6 Right Analog Stick
- 7 Bluetooth LED
- 8 Charging LED
- 9 SELECTION Button
- 10 START Button

- Y Y emission Button
- X X emission Button
- A A emission Button
- B B emission Button

Retractable Smart Phone Holder



①



②




③




④

Android Connect



1. Press “HOME” button in 1s, the indicator flashes, then it starts to work.
2. Press X and Home buttons together about 1 seconds and then release as Blue LED is flashing
(Hold the HOME button for 3 second to turn it off.)
3. It enters into the Bluetooth pairing mode while the Bluetooth LED indicator flashes.
4. Open Bluetooth function of Android device to pair.(Need to be in the could paired mode)
5. It will be in connected mode while the indicator keeps on.



succeeding connection

1. Press X and Home buttons together about 1 seconds and then release as Blue LED is flashing
2. Open Bluetooth function of Android device to pair.(Need to be in the could paired mode)
3. It will be in connected mode while the indicator keeps on.

Note1:


There will be different operating requirements for different Bluetooth versions. If the mobile phone requires password, the default password is 0000 or 1234 (To complete the input and connect while the Bluetooth indicator is flashing continuously)

Note2:

If you want to have "INF-WGP-01" pairing with another phone, please get the original paired phone disconnected or turn off Bluetooth on original mobilephone.

So you can start to connect it with another mobile phone.

i Cade Connect



1. Press B and Home buttons together about 1 seconds and then release as Blue LED is flashing
2. It enters into the Bluetooth pairing mode while the Bluetooth LED indicator flashes.
3. Open Bluetooth function of Android device to pair.
(Need to be in the could paired mode)
4. It will be in connected mode while the indicator keeps on.

Wired Connect

- 1.Android Mode: Use OTG line to connect. When the red indicator stay light on, it indicates that the connection is successful.
- 2.PC Mode:Use USB cable to connect PC and gamepad. When the red indicator stay light on, it indicates that the connection is successful.

Power Off:

Hold the HOME button for 3 second to turn it off.

LED Indicator Status

Type	color	Status
Blue LED indicator	Blue	Flash slowly : No connection Flash quickly : Gonna to Bluetooth pair Stay light on : Pair successfully
Red indicator	Red	Stay light on : On charge Stay light off : Full charge Flash slowly : Low power

Precautions

- 1.When it can not be normal operated, you can use clip to press the reset button at the left back of the controller.
- 2.Do not use and stone it in a hot or humid environment.
- 3.Do not resolve it to avoid damaging it.
- 4.Do not throw it away , due to its built-in battery.
- 5.Please charge fully before using it for the first time
- 6.Recommended continuous charging time of not more than two hours
- 7.Do not disassemble, fall, or approach water / fire sources



保證書

感謝您購買本公司產品 請妥善保管本保證書 以確保完善的售後服務

- 產品自售出之七日內正常使用時出現故障，消費者可選擇免費退、換貨或是修理。購買日起一年內，在正常使用狀況下，如發生故障，由本公司提供免費維修服務。
- 購買時間以經銷商所開出購買發票或收據日期為準。
- 本保證書，請詳填購買日期，並加蓋店章，否則恕不生效。
- 如購機後出現故障，請攜帶發票至經銷商做後續保修服務事宜，如未得到解決，請致電本公司客服，將會在最短的時間內為您服務。
- 下述情況恕不在本公司保固範圍：
 1. 因天災或外力等人為破壞而導致損壞。
 2. 未經本公司同意，自行拆機、修復、改裝。
 3. 正常使用之磨損、破裂、生鏽、浸染。
 4. 無法出示有效購買憑證或保證書。

販售店 店章		購買日期	購買人資料	姓名
				連絡電話

英菲斯國際有限公司
INFANS INTERNATIONAL CO., LTD.

公司地址：台北市松山區八德路四段277之1號3樓
客服地址：新北市五股區五工路124號5樓
公司電話：(02)2793-1260
客服專線：(02)2793-1260